



AgChem Additives by BASF

Emulsifiable Concentrates (EC)

April 2024

Agenda

- 1 | Introduction
- 2 | BASF additives for EC
- 3 | EC testing
- 4 | Solvent system for EC
- 5 | Available test formulations



Formulation types:

Active ingredient physchem properties define formulation type



a.i. is water-soluble

SL – Soluble Concentrate

a.i. dissolved in water (clear to opalescent liquid) e.g. Glyphosate



a.i. is water-insoluble

EC – Emulsifiable Concentrate

a.i. is water-insoluble and dissolved in hydrophobic solvents. Emulsifiers enable spontaneous emulsification upon dilution in water



SC – Suspension Concentrate

A high concentration, stable suspension of finely dispersed a.i.(s) particles in water.



OD – Oil Dispersion

a.i. is insoluble in both oil and water and dispersed as small particles in oil. In the spray tank mix, a suspo-emulsion is formed.



Emulsifiable concentrate


Definition

■ Emulsifiable concentrate (EC)

- ▶ a.i. and emulsifiers dissolved in hydrophobic solvents
- ▶ Water-free
- ▶ EC spontaneously emulsifies upon preparation of spray tank mix
 - Resulting emulsion is stable and a.i. remains in the solvent/oil emulsion droplets


■ Requirements:

- ▶ a.i. has good solubility in the solvent/oil phase
- ▶ Solvents do not degrade a.i.
- ▶ a.i. does not crystallize during storage of the EC or in the aqueous spray mix



Generic emulsifiable concentrate formulation

Function	Content, (g/l)	Comment
Active	50 – 500	1 – 3 actives are typical
Solvents	200 – 800	Water-insoluble, polar
Co-solvent	20 – 100	Either water-soluble or insoluble solvents
Non-ionic emulsifier	60 – 80	Preferably only non-ionics to minimize interactions. Recommendation: 6% Agnique® CSO-35 / 6% Pluronic® PE 9400
Anionic emulsifier	20 – 50	In combination with non-ionics (if required) Recommendation: 8% Agnique® CSO-35 / 4% Agnique® ABS 70 C
Adjuvant	0 – 200	Depends on formulation and a.i. mode of action



Formulation additives selection for EC

■ Solvents


- ▶ Hydrophobic solvents required, stay 5% below max. concentration to avoid a.i. crystallisation at low temperatures
- ▶ Co-solvents can increase a.i. concentration

■ Emulsifiers

- ▶ Spontaneous blooming in water at r.t. and at cold conditions e.g. 4 °C
- ▶ Emulsification in both hard and soft water
- ▶ Reversible creaming can be tolerated
- ▶ Oil separation must be avoided
- ▶ Emulsion should be stable under shear forces to avoid a.i. crystallization in spray solution

■ Adjuvants

- ▶ Some EC solvents (e.g. Agnique[®] AMD 10) provide good adjuvancy by boosting uptake of systemic actives
- ▶ Suitable adjuvant needs sufficient solvency in selected EC solvents



Agenda

- 1 | Introduction
- 2 | **BASF additives for EC**
- 3 | EC testing
- 4 | Solvent system for EC
- 5 | Available test formulations



Product portfolio overview

Solvents and base oils

Dimethyl amides
Alkyl & methyl esters
Carbonates

Adjuvants

Alkoxyated alcohols
Alkyl polyglucosides
Alkyl ether sulfate
Sulfosuccinate

Dispersants

EO-PO-EO copolymers
Polycarboxylates
Sulfonic acid condensates

We offer products from a **broad technology base** using both petrochemical and renewable raw materials

Non-ionic emulsifiers

Castor oil ethoxylates
EO-PO-EO copolymers
Sorbitol ester ethoxylates

Ionic emulsifier

Alkyl benzene sulfonates
Alkyl ether sulfates
Alkyl sulfates

Stickers and thickeners

Epoxidised oils
Polyvinylpyrrolidone homo- and copolymers

Micronutrients and Chelating agents

EDDHA- and EDTA-based micronutrients
EDTA

Sustainability drivers



Products with bio-based content

Product classification ^{a)}	Bio-based carbon [X% of total C]	Icon
Wholly bio-based	$X \geq 95$	
Majority bio-based	$95 > X > 50$	
Minority bio-based	$50 \geq X > 5$	
Non bio-based	$X \leq 5$	



RSPO-certified products

Products available with RSPO mass balance certification



Readily biodegradable products

Readily biodegradable according to OECD 301^{b)}



Label-free according GHS EU criteria^{c)}



Product with negative PCF

Product Carbon Footprint (cradle-to-gate)^{d)}

^{a)} According to the EN17035 surfactants classification

^{b)} In case of mixture all organic components are readily biodegradable

























^{c)} Status of October 2023. Please check the latest MSDS

^{d)} The PCF calculations follow the requirements and guidance given by ISO 14067:2018.



Additives for EC formulations

Solvents

Product	Sustainability profile	Chemistry	Function
Agnique® AMD 810	   	C ₈ /C ₁₀ N,N-dimethyl amide	Hydrophobic solvents allow penetration, however, >300 ml/ha, phytotox may occur depending on crop
Agnique® AMD 10	   	C ₁₀ N,N-dimethyl amide	
Agnique® AMD 12	   	C ₁₂ N,N-dimethyl amide	
Agnique® AE 3-2 EH	 	2-Ethylhexyl lactate ester	Hydrophobic solvent provides adjuvancy
Agnique® ME 1218	    	C ₁₂ -C ₁₈ fatty acid methyl esters	Hydrophobic solvent with adjuvant properties
Propylene Carbonate S		Propylene carbonate	Water miscible solvent
Agnique® AMD 3 L	   	N,N-dimethyl lactamide	Water soluble solvent



Additives for EC formulations

Solvents

Product	Chemistry	Hansen solubility parameter, (MPas ^{1/2})		
		δ_d	δ_p	δ_h
Agnique [®] AMD 810	C ₈ /C ₁₀ N,N-dimethyl amide	15.8	5.3	6.0
Agnique [®] AMD 10	C ₁₀ N,N-dimethyl amide	15.9	4.8	5.7
Agnique [®] AMD 12	C ₁₂ N,N-dimethyl amide	15.9	4.5	4.7
Agnique [®] AE 3-2 EH	2-Ethylhexyl lactate ester	16.0	4.0	11.0
Agnique [®] ME 1218	C ₁₂ -C ₁₈ fatty acid methyl esters	15.9	3.4	4.2
Propylene Carbonate S	Propylene carbonate	16.5	17.0	5.2
Agnique [®] AMD 3 L	N,N-dimethyl lactamide	16.5	11.9	14.2




Agnique® AMD 3 L

Powerful, **label-free, water-miscible solvent**, NMP alternative

Phys.-chem. properties

Chemical structure	N,N-Dimethyl lactamide
Hansen solubility parameter: $\delta_d / \delta_p / \delta_h$ (MPas ^{1/2})	16.5 / 11.9 / 14.2
Boiling point (°C)	223
Flash point (°C)	103
Pour point (°C)	~-60
Density (g/ml) (20°C, 1013 hPa)	1.046
Solvent into water (g/L)	miscible
Log Kow	1.56

Powerful solvent for low soluble a.i.s



Very selective on plants

Test conditions:

- Soya: 4-5 leaf stage
- EC:
 - 90% solvent
 - 10% emulsifier
- Dose rate: 2 L/ha
- Spray rate: 200 L/ha
- Rating: 14 DAT



Agnique® AMD 3 L
No phytotox

Sustainability



Label-free according to GHS criteria^{a)}



Majority bio-based product^{b)}
→ bio-based carbon content between 50-95%



Readily biodegradable according to OECD 301


Test formulation available

ECK-T13: Prothioconazole 18.8%, Fenpropimorph 8.8%

^{a)} Status as of June 2023. Please check the latest MSDS

^{b)} According to the EN17035 surfactants classification

Emulsifier selection for EC



Combination of ionic and non-ionic surfactants
















Non-ionic surfactants are generally compatible with a wide range of solvents, making them a versatile tool


Non-ionic polymeric surfactants stabilize emulsions additionally by steric repulsion

When combined with non-ionics, anionic surfactants give electrostatic stabilization

Additives for EC formulations




Non-ionic emulsifiers

Product	Sustainability profile	Chemistry	Function
Agnique® CSO-30	 	Castor oil ethoxylates	Efficient general-purpose non-ionic emulsifier. Can be combined with Pluronic® PE 9400, Agnique® ABS 70 C or 60 C-EH
Agnique® CSO-35	  		
Agnique® CSO-40	  		
Pluronic® PE 9400		EO-PO-EO blockcopolymer (~40% EO content)	Non-ionic co-emulsifier. Can be combined with Agnique® CSO types
Pluronic® PE 6400	 		
Agnique® SPO 40	   	Sorbitol hexaoleate ethoxylate (40 EO)	Good general-purpose label-free emulsifier



Agrochemical additives


Anionic emulsifiers

Product	Sustainability profile	Chemistry	Function
Agnique® ABS 70 C		Alkyl benzene sulfonate 70% in iso-butanol 58% or 60% in 2-ethylhexanol	Anionic emulsifiers, typically combined with castor oil ethoxylates
Agnique® ABS 58 C-EH			
Agnique® ABS 60 C-EH			



Delivery chain

Adjuvants can not substitute a.i.s or change their mode of action



A step affected by adjuvants

a.i. step affected by phys.-chem. properties of a.i.

Additives for EC formulations

Recommended adjuvants by mode of action

Product	Sustain. profile	Chemistry	Retention	Wetting	Uptake
Agnique® FOH 9 OC-3		Oleyl alcohol ethoxylate			✓
Agnique® KE 3551		Guerbet alcohol alkoxyate	✓	✓	✓
Agnique® SBO 10		Soybean oil ethoxylate			✓
Dehypon® 2574		Fatty alcohol alkoxyate	✓	✓	✓
Dehypon® LS 54		Fatty alcohol alkoxyate	✓	✓	✓
Lutensol® ON 50		C ₁₀ oxo alcohol ethoxylate		✓	
Lutensol® TO 6		Oxo alcohol ethoxylate		✓	✓
Lutensol® TO 8		Oxo alcohol ethoxylate	✓	✓	✓
Lutensol® XL 50		Guerbet alcohol alkoxyate	✓	✓	✓
Lutensol® XP 30		Guerbet alcohol ethoxylate	✓		
Lutensol® XP 80		Guerbet alcohol ethoxylate	✓	✓	✓
Plurafac® LF 224		Oxo alcohol ethoxylate		✓	
Plurafac® LF 300		Oxo alcohol alkoxyate		✓	
Plurafac® LF 431		Guerbet alcohol alkoxyate			✓
Plurafac® LF 901		Guerbet alcohol alkoxyate	✓		
Plurafac® LF 1300		Fatty alcohol ethoxylate			✓
Pluronic® PE 6100		EO/PO block copolymer	✓		

Agenda

- 1 | Introduction
- 2 | BASF additives for EC
- 3 | EC testing**
- 4 | Solvent system for EC
- 5 | Available test formulations



EC testing and results

Overview

- FAO¹ defines standard CIPAC² tests to characterize phys-chem properties
- Additional tests are also used to further validate formulation quality/stability
 - ▶ Stability against crystallisation is tested by storing the concentrate at low temperatures (down to -10°C), typically for 1 week
 - ▶ Circulation pump test to mimic spray tank conditions to ensure no crystal growth

¹ Food and Agricultural Organisation of the United Nations

² Collaborative International Pesticides Analytical Council



Test EC assessment

FAO required CIPAC tests

Property	Comment	CIPAC Method
Appearance	Visual check	
Density (20°C)		CIPAC MT 3.2
Water content	Determine aqueous content	CIPAC MT 30.5
Acidity and/or Alkalinity or pH range	In de-ionized water	CIPAC MT 191 or 75.3
Emulsion stability and re-emulsification	Blooming, spontaneous emulsification in hard and soft water	CIPAC MT 36.3
Persistent foam	Foam after 1 minute	CIPAC MT 47.2
Stability at 0°C	Check for crystallisation, separation	CIPAC MT 39.3
Stability at elevated temperature	14 d at 54°C, or 28 d at 50°C, or 8 weeks at 40°C. Recheck for by-products, acidity/alkalinity, emulsification	CIPAC MT 46.3

EC Testing – emulsion stability

Method: CIPAC MT 36.3

- CIPAC defines emulsion stability at 5% aqueous dilution in a measuring cylinder
 - ▶ However, farmer commonly dilutes 1 l EC into 200 l spray mix (0.5%)
 - ▶ Emulsion stability is therefore assessed at both 0.5 and 5 %
 - ▶ Hard and soft water dilutions are assessed
 - ▶ Low temperature emulsion stability is also required
- Emulsion stability assessed by measuring the following parameters:
 - ▶ ‚Cream‘ which can be re-emulsified (reversible)
 - ▶ ‚Oil‘ which has separated (irreversible)
 - ▶ Precipitation at the bottom of the cylinder
 - ▶ „ease“ of re-emulsification after 24 h storage



EC Testing – emulsion stability

Blooming and spray mix storage

Emulsion stability: CIPAC MT 36.3

instant
blooming




after
1h




after
2h



after
4h



Emulsion instability.
Herein, phase separation has occurred



Example EC formulation: Tebuconazole EC 280, ECK-T02

Component	Function	% w/w
Tebuconazole	Active	28.5
Agnique® AMD 10	Solvent	61.5
Agnique® CSO-35	Non-ionic emulsifier	10.0

Stability Emulsion (5% EC) Water quality: CIPAC D

t = 0	1 (milky)
t = 1h	stable
t = 2h	stable
t = 4 h	stable
t = 24h	2 ml cream
Re-emulsification	stable



EC Testing – emulsion shear stability

Circulation pump test

■ Emulsions can become unstable under shear forces


- ▶ Emulsions formed in the spray tank are circulated under shear until application to crops
- ▶ Any crystallisation/precipitation during circulation will block the spray nozzles
- ▶ This must be avoided!

■ Method

- ▶ Lab-based circulation equipment (next slide)
- ▶ Testing under harsh conditions: e.g. 0.5% dilution, hard water, 5°C
- ▶ Control pressure and flow rate
- ▶ Assess precipitate collected on 140 μ filter after 6 h

■ Monitor crystal formation

- ▶ Filter must not be clogged after 6 h
- ▶ Determine residues by weighing filter




EC Testing – emulsion shear stability

Circulation pump test equipment

Target: 0.5% emulsion (e.g. in CIPAC D water) circulated through filter over 6 h

Technical data:

Mesh size: 140 μm
Pressure limit: 4.5 bar
Flow rate: 1 l/min



Agenda

- 1 | Introduction
- 2 | BASF additives for EC
- 3 | EC testing
- 4 | **Solvent system for EC**
- 5 | Available test formulations



Fatty acid dimethyl amides for EC formulations

- Agnique® AMD 810 or AMD 10 are excellent solvents
 - ▶ Proven record for more than two decades in Tebuconazole EC and EW
 - ▶ Prothioconazole & Difenconazole EC in combination with co-solvents
 - ▶ Propiconazole, Cyproconazole EC with water miscible co-solvent
 - ▶ In another EC, Epoxiconazole is combined with strobilurin
 - ▶ Corresponding EC test formulations available


- Agnique® AMD 12 is an alternative for EC formulations
 - ▶ Pour point of Agnique® AMD 12 at +8 °C
 - ▶ Co-solvents are required



Limited Availability of C₈/C₁₀ Dimethylamides

Raw materials extracted from fatty acids

Carbon fraction split in different vegetable oils



- C₁₂ fraction in palm kernel and coconut oil is significantly higher
- Agnique® AMD 12 → N,N-dimethyl dodecanamide



EC Formulations with Fatty Acid Amides like Agnique[®] AMD 12

■ Advantages:

- ▶ Based on lauric acid, Agnique[®] AMD 12 has better availability
- ▶ Agnique[®] AMD 12 shows good solvency

■ Challenges:

- ▶ But has a high pour point → $T_m = 8^{\circ}\text{C}$
- ▶ Emulsification can be a challenge without co-solvent



■ Solution:

- ▶ Fine-tuning of solvents mixture in formulation to increase cold stability and improve emulsion stability



Example Formulations with Agnique® AMD 12, ME 1218 and PC

Fine-tuning of solvents mixture to achieve target formulation




*Emulsion stability linked to solvent water solubility

Good Emulsification of Agnique® AMD 12 with co-solvents

Examples: Oxyfluorfen EC with different hydrophobic co-solvents

Components (% w/w)	Reference	A	B	C
Oxyfluorfen	20	20	20	20
Agnique® AMD 12	32.5	27.5	27.5	27.5
Agnique® ME 1218		10		
Agnique® ME 610			10	
Cetiol® B				10
Propylene Carbonate S	32.5	27.5	27.5	27.5
Agnique® CSO-40	10	10	10	10
Pluronic® PE 6400	5	5	5	5
Re-circulation test	✘	✔	n.d.	n.d.

Emulsion stability (CIPAC MT 36.3), EC diluted in CIPAC D water



Various hydrophobic esters can be used as co-solvents

Easier Emulsification of Hydrophobic Solvents

Triangle approach offers high flexibility

- Tested formulations are stable and liquid at -5 °C
 - ▶ Elevated concentrations of Agnique[®] AMD 12 lead to solid EC formulations below -5°C
 - ▶ Higher levels of propylene carbonate lead to emulsion instability and a.i. crystallization
- Formulation a.i. concentration can be fine-tuned by careful selection of FADMA, fatty acid ester and hydrophilic solvent contents
- Fatty acid amides and fatty acid esters can enhance uptake of systemics

- Corresponding patent filed

Agenda

- 1 | Introduction
- 2 | BASF additives for EC
- 3 | EC testing
- 4 | Solvent system for EC
- 5 | **Available test formulations**



Available Test Formulations

Please contact us for the further information

Fungicides

ECK-T01 / T02	Tebuconazole 300 & 285
ECK-T03 / T04	Tebuconazole 200
ECK-T09 / T14	Difenoconazole 200
ECK-T10	Cyproconazole 200
ECK-T13	Prothioconazole 190/ Fenpropimorph 90
ECK-T17	Prochloraz 225/ Tebuconazole 125/ Fenpropimorph 190
ECP-H20	Tebuconazole 200 / Propiconazole 200
ECP-H21	Epoxiconazole 60 / Pyraclostrobin 60

Fungicides

ECC-S27	Pyraclostrobin 200
ECC-S28	Propiconazole 250 / Cyproconazole 160
ECC-S29	Prothioconazole 175 / Difenoconazole 125
ECP-H30	Epoxiconazole 60 / Pyraclostrobin 60
ECP-H34	Tebuconazole 250
Insecticides	
ECK-T18	Abamectin 18

Herbicides

ECK-T05 / T06	Oxyfluorfen 250
ECK-T07	Oxyfluorfen 230
ECK-T11 / T12	Fluroxypyr-meptyl 400
ECK-T16	Flufenacet 200
ECC-S25	Pinoxaden 50 / Cloquintocet 10
ECC-S26	Fenoxaprop-p-ethyl 100/ Mefenpyr-diethyl 270


Our top recommendations



Register and explore
our new product finder!



Product Finder at
www.care360.basf.com



Disclaimer

This document, or any answers or information provided herein by BASF, does not constitute a legally binding obligation of BASF. While the descriptions, designs, data and information contained herein are presented in good faith and believed to be accurate, they are provided for your guidance only. Because many factors may affect processing or application/use, we recommend that you make tests to determine the suitability of a product for your particular purpose prior to use. It does not relieve our customers of the obligation to perform a full inspection of the products upon delivery or any other obligation. The claims and supporting data provided in this publication have not been evaluated for compliance with any jurisdiction's regulatory requirements and the results reported may not be generally true under other conditions or in other matrices. Users must evaluate what claims and information are appropriate and comply with a jurisdiction's regulatory requirements. **NO WARRANTIES OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE MADE REGARDING PRODUCTS DESCRIBED OR DESIGNS, DATA OR INFORMATION SET FORTH, OR THAT THE PRODUCTS, DESIGNS, DATA, OR INFORMATION MAY BE USED WITHOUT INFRINGING THE INTELLECTUAL PROPERTY RIGHTS OF OTHERS. IN NO CASE SHALL THE DESCRIPTIONS, INFORMATION, DATA, OR DESIGNS PROVIDED BE CONSIDERED A PART OF OUR TERMS AND CONDITIONS OF SALE.**



We create chemistry